EtherNet/IP[™] Interface

Interface for the 1280 and 880 Indicators

Installation and Programming Manual



COMPATABILITY NOTICE: If card no longer communicates correct data, change SWAP parameter to "BYTE" in the indicator



PN 156861 Rev D

January 7, 2020

An ISO 9001 registered company © Rice Lake Weighing Systems. All rights reserved.

Rice Lake Weighing Systems[®] is a registered trademark of Rice Lake Weighing Systems. All other brand or product names within this publication are trademarks or registered trademarks of their respective companies.

All information contained within this publication is, to the best of our knowledge, complete and accurate at the time of publication. Rice Lake Weighing Systems reserves the right to make changes to the technology, features, specifications and design of the equipment without notice.

The most current version of this publication, software, firmware and all other product updates can be found on our website:

www.ricelake.com

Contents

1.0	Introduction		
2.0	Installation 2 2.1 LED Status Indicators 6		
3.0	Configuring the Network Settings73.1 Configuring a Generic EtherNet/IP Module83.2 Sample for BYTE Swapping in a PLC93.3 Sample BYTE Swapping10		
4.0	Commands 11 4.1 Output Data Format 11 4.1.1 BYTE Swapping 14 4.2 Input Data Format 14 4.2.1 Command number 15 4.2.2 Status Data 15 4.2.3 Value 17 4.2.4 Setting a Float Value 17 4.2.5 Reading a Float Value 17 4.3 Command Descriptions 17		
5.0	Specifications		



Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at **www.ricelake.com/training** or obtained by calling 715-234-9171 and asking for the training department.

EtherNet/IP Interface



Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit www.ricelake.com/webinars.

Visit our website www.RiceLake.com



1.0 Introduction

The EtherNet/IP Interface can be used to read and write data to the indicator using a PLC or another primary controller. This manual provides information for installation and use of this product.

The EtherNet/IP Interface is installed inside the indicator enclosure and installation in NEMA Type 4X stainless steel enclosures permits use in washdown environments.

See the indicator technical manual for additional installation information and detailed descriptions of indicator functions.



Some procedures described in this manual require work inside the indicator enclosure. These procedures are to be performed by qualified service personnel only.



Manuals and additional resources are available on the Rice Lake Weighing Systems website at <u>www.ricelake.com</u>

Warranty information can be found on the website at www.ricelake.com/warranties

1.1 Overview

EtherNet/IP Interface (Ethernet Industrial Protocol) is an open industrial networking standard allowing control applications to make use of Ethernet communications components and physical media.

EtherNet/IP Interface is based on the IEEE 802.3 Ethernet standard, the TCP/IP protocol suite, and CIPTM (Common Industrial Protocol), the real-time I/O and information protocol used by both DeviceNetTM and ControlNetTM networks.

The EtherNet/IP Interface returns weight and status information from an indicator to the network and provides limited control of indicator functions to the programmer. Indicator configuration and calibration cannot be performed through the EtherNet/IP Interface.

2.0 Installation

EtherNet/IP Interface specific functions are provided by an Etheret/IP module.

The module plugs into an open slot on the CPU board and provides power and access from the indicator bus to the module.

IMPORTANT See the indicator Technical Manual for installation instructions.

The interface option cards of the 1280 Enterprise Series and 880 universal and panel mount indicators share the same carrier board (PN 164756). The carrier board plugs into an open slot on the CPU board and provides power and access from the indicator bus to the module. The assembly steps of the carrier board and modules vary between the 1280, 880 universal mount, and 880 panel mount.

- 1280 interface option card kits are shipped with the module and the carrier board already assembled
- · 880 interface option card kits are shipped with the module and carrier board separated
 - 880 universal mount module can be assembled to the carrier board before installing
 - $-\,$ 880 panel mount carrier board must be installed before assembling the module to the carrier board



Figure 2-1. Interface Option Card Kit

The indicator automatically recognizes all installed option cards when the unit is powered on. No hardware-specific configuration is required to identify an installed card to the system.



Always disconnect the power before opening an enclosure. Interface option cards are not hot swappable.

A grounding wrist strap must be worn to protect components from electrostatic discharge (ESD) when working inside an enclosure or controller assembly.



1280 Installation Instructions

- 1. Disconnect power to the indicator.
- 2. See the 1280 technical manual (PN 167659) to gain access to the Controller Assembly box for the specific model.
- 3. Remove the screw securing the intended slot cover plate of the Controller Assembly box, set the slot cover plate aside and save the screw.
- 4. Mount the faceplate on module and slide module board assembly into place within the slot.
- 5. Secure the faceplate and module board assembly into place with the previously removed screw.



Interface cable is routed through a cord grip in Universal and Wall mount enclosures.

Alternately, a chassis mounted connect can be installed in the enclosure.

6. See 1280 technical manual to reinstall the Controller Assembly box.



Figure 2-2. Existing Cover Plate Removal



Figure 2-3. Installed Interface Option Card

880 Universal Installation Instructions

- 1. Disconnect power to the indicator.
- 2. Remove the backplate of the universal enclosure to access the CPU board.
- 3. Carefully slide the module into the J1 connector on the carrier board, ensuring that the pins of J1 are not bent.
- 4. Ensure that the module is fully seated in the carrier board with the board hooks on the bottom of the module aligned with the carrier board.
- 5. Tighten module screws on the front of the module to lock the board clamps of the module to the carrier board.



Figure 2-4. Bottom of Carrier Card with Module Installed



Screws are tightened with a T9 Torx bit.

If the module is not fully seated on the carrier board, the clamps will push the module away from the board rather than securing the board to the module. This can potentially cause damage to the connector.

- 6. Carefully align the J5 connector on the bottom of the carrier board with the J8 option card slot on the CPU board.
- 7. Press down on the carrier board with module until it is seated on the CPU board connector.
- 8. Use the screws provided in the option kit to secure the carrier board to the threaded standoffs on the CPU board (faceplate not needed).
- 9. Connect and properly run necessary cable.
- 10. Reinstall the enclosure backplate.



880 Panel Mount Installation Instructions

- 1. Disconnect power to the indicator and then disconnect the display cable.
- 2. Remove the backplate of the panel mount enclosure to access the CPU board.
- 3. Carefully align the J5 connector on the bottom of the carrier board (module currently not attached) with J8 option card slot on the CPU board.
- 4. Press down on the carrier board until it is seated on the CPU board connector.
- 5. Use the screws provided in the option kit to secure the carrier board and faceplate to the threaded standoffs on the CPU board.
- 6. Carefully slide the module through the faceplate to the J1 connector on the carrier board, ensuring that the pins of J1 are not bent.
- 7. Ensure that the module is fully seated in the carrier board with the board hooks on the bottom of the module aligned with the carrier board.
- 8. Tighten T9 Torx screws on the front of the module to lock the board clamps of the module to the carrier board.



Screws are tightened with a T9 Torx bit.

If the module is not fully seated on the carrier board, the clamps will push the module away from the board rather than securing the board to the module.



Figure 2-5. 880 Panel Mount Interface Option Card Installation

9. Reinstall the enclosure backplate and then reconnect the display cable.

EtherNet/IP Interface

2.1 LED Status Indicators

An LED array on the EtherNet/IP module provides status information for troubleshooting.



Figure 2-6. EtherNet/IP Module



Note A test sequence is performed on LED (item 1 and 2 below) during startup.

Network Status LED (Item 1)

LED State	Description
Off	No power or no IP address
Green	Module is in Process Active or Idle state
Green, Flashing	Waiting for connections
Red	Duplicate IP address, FATAL event
Red, Flashing	Process Active Timeout

Table 2-1. Network Status LED

Module Status LED (Item 2)

LED State Description		
Off	No power	
Green	Normal operation	
Green, Flashing Not configured or Scanner in idle status		
Red Major fault; Module is in state EXCEPTION (or FATAL ev		
Red, Flashing	Minor fault in diagnostic object; IP conflict	

Table 2-2. Module Status LED

Link/Activity LED (Item 3)

LED State	Description
Off	No link, no activity
Green	Link established
Green, Flickering	Activity

Table 2-3. Link/Activity LED

RJ45 Port (Item 4)

The EtherNet/IP interface supports 10/100Mbit, full or half duplex operation.



3.0 Configuring the Network Settings

Configuring the network setting is done using a web browser or Anybus IP configuration utility.

To set the network settings using a web browser.

- 1. Open a browser and type the IP address of the card.
- 2. Change any or all settings.
- 3. Click on Store settings.

To set the network settings using the Anybus IP Configuration program.

- 1. Open the configuration program found on the CD.
- 2. Click on Scan button if the device does not display in the menu.
- 3. Double click on the device. A menu is displayed with the current network settings.
- 4. Change any or all settings.
- 5. Click on the Set button.

The following are examples only, actual displays will vary:

Network interface Parameter data		
Anybus	-CC EtherNet/IP	
N	letwork interface	
Serial#:	0xA0150A66	
MAC ID:	00:30:11:05:F8:3A	
Firmware version:	2.05 Build 3	
	0 days, 0h 7m 27s	
Uptime:		

Figure 3-1. EtherNet/IP Interface Display in a Web Browser



IP Configuration			
IP address:	10.2.58.126		
Subnet mask:	255.255.255.0 0.0.0.0		
Gateway:			
Host name:			
Domain name:			
DNS1:	0.0.0.0		
DNS2:			
DHCP:	\checkmark		
	Store settings		
SMTP Settings			
SMTP Server:			
SMTP User:			
SMTP Pswd:			
	Store settings		
Ethernet Configuration			
Comm Settings:	Auto 🗸		
	Store settings		

Anybus-CC EtherNet/IP

Network configuration

Figure 3-2. EtherNet/IP Configuration in a Web Browser

IMPORTANT

The DHCP is set to on in the factory and there is not a default IP address.

3.1 Configuring a Generic EtherNet/IP Module

See Figure 3-3 to configure a generic EtherNet/IP module in a CompactLogix or ControlLogix PLC.

Type: Vendor: Parent:	ETHERNET-MODULE Allen-Bradley LocalENB	Generic Etherne	t Module			
Name:	Scale_880		Connection Para	ameters		
Description:	l =			Assembly Instance:	Size:	
	test	÷	Input	100	4	
	1	*	O <u>u</u> tput:	150	4	
Comm <u>F</u> orma	t Data - INT	*	Configuration:	1	0	
-Address / H	lost Name			<u></u>	-	
	ess: 10 . 2 . 5	58 . 126	<u>Status Input</u>			
с <u>H</u> ost N	ame:		Status Output:			

Figure 3-3. Generic EtherNet/IP Module Screen



3.2 Sample for BYTE Swapping in a PLC

See Figure 3-4 for an example of BYTE Swapping in a PLC when setting or reading a floating point value.

Use the following rungs when sending or reading floating point data:

EthernetIP - Ladder Diagram Page 1 test_copy_command:MainTask:MainProgram 8/17/2007 2:33:14 PM C:\RSLogix 5000\Projects\test_copy_command.ACD Total number of rungs in routine: 10 Special swapping for EtherNet IP is needed. Rungs 1 - 3 take the inputs from the EtherNet card and swap them in to an array on integers. NOTE: An array needs to be used in order for the copy command to be use. Reading the weight in integer format is as simple as putting a zero value in EthIP_output[0] since zero is the default you will the scale weight in EthIP_input[2]. SWPB Swap Byte 0 Source RLWS:1.Data[0] 8193 Order Mode HIGH/LOW Dest EthIP_input[0] 288 SWPB Swap Byte Source RLWS:I.Data[1] 2305 Order Mode HIGH/LOW EthIP_input[1] Dest 265 This one needs to be swapped with 3 in order to make float commands work. SWPB Swap Byte 2 Source RLWS:1.Data[2] 12611 Order Mode HIGH/LOW EthIP_input[3] Dest 17201 This one needs to be swapped with 2 in order to make float commands work SWPB Swap Byte 3 Source RLWS:I.Data[3] Order Mode HIGH/LOW Dest EthIP_input[2] Rungs 4 - 7 swap the user tags before they are sent back to the EtherNet IP card. NOTE: Arrays need to be used so that the copy command can be used SWPB Swap Byte 4 Source EthIP_output[0] 288 Order Mode HIGH/LOW RLWS:O.Data[0] Dest 8193 Figure 3-4. Ladder Logic for EtherNet/IP Page 1



EtherNet/IP Interface

3.3 Sample BYTE Swapping

See Figure 3-5 for an example of BYTE Swapping for all other commands.

	Swap Bute
	Source EthIP_output[1]
	1
	Order Mode HIGH/LOW
	256
This one needs to be swapped with 2 in order to make float commands we	ork. So the correct value is sent
	SWPB
	Swap Byte
	Source EthiP_output[2]
	Order Mode HIGH/LOW
	Dest RLWS:O.Data[3]
	0
	Source EthIP_output[3] Order Mode HIGH/LOW Dest RLWS:O.Data[2]
Use the copy command to convert the two integers from the array to a float. This i command is used like command # 288	s used to read the scale weight if a
	Copy File
	Source EthIP_input[2]
	Dest Real[3]
	Length
When you need to send a value to the indicator use the copy command to convert sent.	a float value to the two integers the
	Copy File
	Source Real[4]
	Dest EthIP_output[2]
	Length 2

RSLogix 5000

Figure 3-5. Ladder Logic for EtherNet/IP Page 2

4.0 Commands

Commands are used by the primary device to send and receive data from the interface as integer or floating-point data. The primary sends eight bytes in the output format to write commands to the indicator and reads eight bytes in the input format to read data from the indicator.

Decimal Point Handling

Integer commands return no decimal point information to the primary.

For example, a value of 750.1 displayed on the indicator is returned to the primary as 7501. Floating point commands support decimal point information with no special handling.

4.1 Output Data Format

To perform a command, the primary uses the output command format to send four 16-bit words to the interface. These four words contain the command and the necessary parameters to execute it. The output command format is shown in Table 4-1.

Word	Description
Word 1	Command Number
Word 2	Parameter
Word 3	Value (MSW)
Word 4	Value (LSW)

Table 4-1. 880 Output Data Format

Byte	Description	
Byte 0	Command Number	
Byte 1		
Byte 2	Deremeter	
Byte 3	Falametei	
Byte 4	Value (MSW)	
Byte 5		
Byte 6	Value (LSW)	
Byte 7		

Table 4-2. 1280 Output Data Format



See Section 4.1.1 on page 14 for BYTE swapping parameters. A lockout feature, incorporated into the indicator receive mechanism, looks for change in the output format data to prevent inundation by the same command. See affected commands noted in Table 4-3 on page 12 with an (*). Repeated commands must be separated by any other valid command/parameter/ value combination.

Parameter Value

In communication with a multi-scale indicator, the scale number is sent in the second word of the output command format. Zero (0) represents the current scale. Certain commands require a parameter other than a scale number, such as a slot number, setpoint number, or other selection parameter. See the command descriptions for specific command requirements.

Value

The third and fourth words of the output format are used to pass value data on certain commands. Values entered in these words are treated as unsigned long integers or floating-point values, depending on the command.

Command Number

The number representing the indicator command is sent in the first word. Table 4-3 lists the commands that can be specified for indicators.

Some commands may not be available on all indicators.

Decimal	Hex	Command
0	0x000	Return Status and Weight (integer)
1	0x001	Display Channel
2	0x002	Display Gross Weight
3	0x003	Display Net Weight
9	0x009	Gross/Net key press (toggle)
10	0x00A	Zero*
11	0x00B	Display Tare*
12	0x00C	Enter Tare*
13	0x00D	Acquire Tare*
14	0x00E	Clear Tare*
16	0x010	Primary Units
17	0x011	Secondary Units
18	0x012	Tertiary Units
19	0x013	Units key press (toggle units)
20	0x014	Print Request
21	0x015	Display Accumulator
22	0x016	Clear Accumulator
23	0x017	Push Weight to Accumulator
32	0x020	Return Gross (integer)
33	0x021	Return Net (integer)
34	0x022	Return Tare (integer)
37	0x025	Return Current Display (integer)

Table 4-3. Remote Commands

Decimal	Hex	Command	
38	0x026	Return Accumulator (integer)	
39	0x027	Return Rate of Change (integer) 1280 only	
95	0x05F	Set Batching State	
96	0x060	Batch Start	
97	0x061	Batch Pause	
98	0x062	Batch Reset	
99	0x063	Batch Status	
112	0x070	Lock Indicator Front Panel	
113	0x071	Unlock Indicator Front Panel	
114	0x072	Set Digital Output ON	
115	0x073	Set Digital Output OFF	
116	0x074	Read Digital I/O Status	
128	0x80	Enable Bus Command Handler	
253	0x0FD	No operation	
254	0x0FE	Reset Indicator	
256	0x100	Return Status and Weight (float)	
268	0x10C	Enter Tare (float)	
288	0x120	Read Gross (float)	
289	0x121	Read Net (float)	
290	0x122	Read Tare (float)	
293	0x125	Read Current Display (float)	
294	0x126	Read Accumulator (float)	
295	0x127	Read Rate of change (float) 1280 only	
304	0x130	Set Setpoint Value (float)	
305	0x131	Set Setpoint Hysteresis (float)	
306	0x132	Set Setpoint Bandwidth (float)	
307	0x133	Set Setpoint Preact (float)	
320	0x140	Read Setpoint Value (float)	
321	0x141	Read Setpoint Hysteresis (float)	
322	0x142	Read Setpoint Bandwidth (float)	
323	0x143	Read Setpoint Preact (float)	

Table 4-3. Remote Commands (Continued)

4.1.1 BYTE Swapping

Note See the Ports Menu in the indicator manual.

The indicator sends and receives data in integer format.

The standard format is as follows for all input and output values:

High BYTE - Low BYTE

If the indicator FLDBUS/SWAP parameter is set to YES, then the BYTE order changes to:

Low BYTE – High BYTE

Example: If the weight on the scale reads 10 lbs and a value of 2560 is displayed in the PLC, either swap the BYTES in the PLC or change the SWAP parameter to YES.

4.2 Input Data Format

In response to a command, the interface returns data and status information to the primary as four 16-bit words. This information is returned in the input command format shown in Table 4-4. The value type can be set for those commands that do not specify integer or floating point data by sending a command 0x000 to specify integer data or command 0x100 for floating-point data. The value type is returned in the status word (bit 14) of the input format.

Word	Description
Word 1	Command Number
Word 2	Status
Word 3	Value (MSW)
Word 4	Value (LSW)

Table 4-4. 880 Input Data Format

Byte	Description	
Byte 0	Command Number	
Byte 1		
Byte 2	Status	
Byte 3	Status	
Byte 4	Value (MSW)	
Byte 5		
Byte 6	Value (LSW)	
Byte 7		

Table 4-5. 1280 Input Data Format



See Section 4.1.1 for BYTE swapping parameters.

4.2.1 Command number

The first word echoes the command number. If the command fails or is not recognized, the negative of the command number is returned to signal the error.

4.2.2 Status Data

Indicator status data is returned in the second word (Table 4-6). Batch commands return batch status in place of the low byte (Table 4-7 on page 16). Setpoint commands return batch status in the low byte of the status word and the setpoint number in the high byte.

Word 2	Indicator Status Data			
Bit	Value=0	Value=1		
00	Error **	No error		
	(Bit-0 Errors on page 16)			
01	Tare not entered	Tare entered		
02	Not center of zero	Center of zero		
03	Weight invalid	Weight OK		
04	Standstill	In motion		
05	Primary units	Other units		
06	Tare not acquired	Tare acquired		
07	Gross weight	Net weight		
08				
09	Channel number			
10				
11	NOTE: Least significant bit first.			
12				
13	Not used			
14	Integer data	Floating point data		
15	Positive weight	Negative weight		
This error condition does not necessarily mean the weight being reported is invalid. Refer to the "Weight invalid" bit.				

Table 4-6. Indicator Status Data Format

EtherNet/IP Interface

Bit-0 Errors

- · PLC command failed to execute
- No configuration has taken place
- Scale parameter is out of range
- · Print error has occurred
- · Load error has occurred
- · Memory error has occurred
- · Analog to digital converter error
- Tare error
- · Scale over range error
- · Scale under range error
- · Non-recoverable configuration store error
- · Indicator in configuration mode

Word 2	Batch Function Status Data		
Bit	Value=0	Value=1	
00	Digital input 4 OFF	Digital input 4 ON	
01	Digital input 3 OFF	Digital input 3 ON	
02	Digital input 2 OFF	Digital input 2 ON	
03	Digital input 1 OFF	Digital input 1 ON	
04	Batch not paused	Batch paused	
05	Batch not running	Batch running	
06	Batch not stopped	Batch stopped	
07	Alarm OFF	Alarm ON	
08			
09			
10	Setpoint number		
11			
12]		
13	Not used		
14	Integer data	Floating point data	
15	Positive weight	Negative weight	

Table 4-7. Batch Function Status Data Format

4.2.3 Value

Weight data is returned to the primary in the third and fourth words of the input command format, depending on the command and the value type. The weight data returned is the displayed weight after the command is executed, unless the command specifies otherwise. A negative value is returned in the two's compliment format.

4.2.4 Setting a Float Value

Setting a float value in a setpoint requires the value to be sent in two separate integer values. Most PLCs have a mechanism to take a float value and separate it into to integer values.

Example: The following must be sent in the output words to set the value of Setpoint #1 to 10000.

Command word = 304

Parameter word = 1 MSW = 17948 LSW = 16384

4.2.5 Reading a Float Value

When a float value is read it will be returned in two integers representing the float value. The PLC must combine MSW and LSW integer values back into a float value.

Example: The following is returned in the input words if the weight on the scale is 800.5.

Command Word = 288 Status word = Scale status MSW= 17480 LSW = 8192

4.3 Command Descriptions

Return Status and Current Weight as Integer

Command: 0, 0x000

Parameter: Scale number

Command 0 returns the status and gross or net scale weight (per scale configuration) of the specified scale in integer format, without changing the display. This command also causes the format-independent commands to return a value in the integer format.

Display Channel

Command: 1, 0x001

Parameter: Scale number

Command 1 causes the weight of the specified scale to be displayed and returned in its current mode and format.



EtherNet/IP Interface

Display Gross Weight

Command: 2, 0x002 Parameter: Scale number Command 2 causes the gross weight of the specified scale to be displayed and returned.

Display Net Weight

Command: 3, 0x003 Parameter: Scale number Command 3 causes the net weight of the specified scale to be displayed and returned.

Gross/Net Key Press (Toggle Mode)

Command: 9, 0x009 Parameter: Scale number Command 9 toggles between gross and net mode (and count mode, if enabled). If a scale number other than 0 is specified, the action will not be seen until the specified scale is displayed.

Zero

Command: 10, 0x00A Command 10 performs a **ZERO** operation on the current scale.

Display Tare

Command: 11, 0x00B

Parameter: Scale number

Command 11 causes the tare weight on the specified scale to be displayed. If a scale number other than 0 is specified, the indicator first causes the specified scale to be displayed. Display returns to the prior mode after checking the indicator.

Enter Tare (Integer)

Command: 12, 0x00C Parameter: Scale number Value: Tare weight Command 12 enters a tare for the scale selected. Tare data must be in integer format. The indicator continues to return weight data in the current mode for the specified scale.

Acquire Tare (Simulate TARE Key Press)

Command: 13, 0x00D

Parameter: Scale number

Command 13 acquires a tare based on the weight currently on the specified scale. The indicator continues to return weight data in the current mode for the specified scale.

Clear Tare

Command: 14, 0x00E

Parameter: Scale number

Command 14 clears the tare for the specified scale. The indicator continues to return weight data in the current mode for the specified scale.

Primary Units

Command: 16, 0x010

Parameter: Scale number

Command 16 switches the current format of the specified scale to the primary units configured for that scale.

Secondary Units

Command: 17, 0x011 Parameter: Scale number Command 17 switches the current format of the specified scale to the secondary units configured for that scale.

Tertiary Units

Command: 18, 0x012 Parameter: Scale number Command 18 switches the current format of the specified scale to the tertiary units configured for that scale, if available.

Units Key Press (Toggle Units)

Command: 19, 0x013 Parameter: Scale number Command 19 toggles between primary and secondary units of the specified scale.

Print Request

Command: 20, 0x014 Parameter: Scale number Command 20 causes the indicator to execute a print command for the current scale.

Display Accumulator

Command: 21, 0x015 Parameter: Scale number

Command 21 causes the value of the accumulator for the specified scale to be displayed and returned. This command is valid only when the accumulator for the specified scale is enabled.



Clear Accumulator

Command: 22, 0x016 Parameter: Scale number Command 22 clears the value of the accumulator for the specified scale. This command is valid only when the accumulator for the specified scale is enabled.

Push Weight to Accumulator

Command: 23, 0x017 Parameter: Scale number

Command 23 adds the net weight on the specified scale to the value of the accumulator for the specified scale. The scale must return to net zero between accumulations. The indicator returns the accumulated weight data for the specified scale. This command is valid only when the accumulator for the specified scale is enabled.

Return Gross as Integer

Command: 32, 0x020 Parameter: Scale number Command 32 returns the gross weight value for the specified scale as an integer.

Return Net as Integer

Command: 33, 0x021 Parameter: Scale number Command 33 returns the net weight value for the specified scale as an integer.

Return Tare as Integer

Command: 34, 0x022 Parameter: Scale number Command 34 returns the tare weight value for the specified scale as an integer.

Return Current Display as Integer

Command: 37, 0x025 Parameter: Scale number Command 37 returns the weight value for the specified scale as currently displayed. This may include gross, net, tare, or accumulator values, as enabled.

Return Accumulator as Integer

Command: 38, 0x026 Parameter: Scale number Command 38 returns the accumulator value for the specified scale. This command is valid only when the accumulator for the specified scale is enabled.

Return Rate of Change as Integer

Command: 39, 0x027 Parameter: Scale number Command 39 returns the current rate of change value for the specified scale. This command is valid only for the 1280.

Set Batching State

Command: 95, 0x05F Parameter: State (0 = off; 1 = auto; 2 = manual) Command 95 sets the batching (BATCHNG) parameter. Indicator status is returned with the current weight for the last scale specified.

Batch Start

Command: 96, 0x060 Parameter: Scale number Command 96 starts a batch program from the current step after a stop, pause, or reset. Batch status is returned with the current weight for the specified scale.

Batch Pause

Command: 97, 0x061 Parameter: Scale number Command 97 pauses a batch program at the current step. Batch status is returned with the current weight for the specified scale.

Batch Reset

Command: 98, 0x062 Parameter: Scale number Command 98 stops a batch program and resets it to the first batch step. Batch status is returned with the current weight for the specified scale.

Batch Status

Command: 99, 0x063 Parameter: Scale number Command 99 returns the status of a batch. Batch status is returned with the current weight for the specified scale.

Lock Front Panel of Indicator

Command: 112, 0x070 Parameter: Scale number Command 112 disables all the keys on the front panel of the indicator. Indicator status is returned with the current weight for the specified scale.

Unlock Front Panel of Indicator

Command: 113, 0x071 Parameter: Scale number Command 113 re-enables all the keys on the front panel of the indicator. Indicator status is returned with the current weight for the specified scale.

Set Digital Output ON

Command: 114, 0x072 Parameter: Slot number Value: Bit number Command 114 sets the specified digital output ON (active). Use slot number 0 for onboard digital outputs. Indicator status is returned with the current weight for the last scale specified.

Set Digital Output OFF

Command: 115, 0x073 Parameter: Slot number Value: Bit number Command 115 sets the specified digital output OFF (inactive). Use slot number 0 for onboard digital outputs. Indicator status is returned with the current weight for the last scale specified.

Read Digital I/O

Command: 116, 0x074

Parameter: Slot number

Command 116 returns the status for all digital I/O in the specified slot in words 3 and 4. Use slot number 0 for onboard digital I/O. Indicator status is returned in the status area for the last scale specified.

Enable Bus Command Handler

Command: 128, 0x80 Parameter: None Command 128 enables the bus command handler in a user program. While this handler is enabled, all other PLC commands are disabled.

No Operation

Command: 253, 0x0FD

Parameter: Scale number

Command 253 provides a command to use between operations, as necessary, without causing the indicator to perform any action. Indicator status and weight for the specified scale is returned.

Reset Indicator

Command: 254, 0x0FE Parameter: None Command 254 provides a command to remotely reset the indicator. No data is returned.

Return Status and Current Weight as Float

Command: 256, 0x100

Parameter: Scale number

Command 256 returns the status and weight of the specified scale in floating-point format, without changing the display. This command also causes the format-independent commands to return a value in the floating-point format. Returns current weight at a floating-point format.

Enter Tare as Float

Command: 268, 0x10C Parameter: Scale number Value: Tare weight Command 268 enters a tare for the scale selected in floating-point format. The indicator returns the tare weight as taken, or 0 for no tare.

Read Gross Weight as Float

Command: 288, 0x120 Parameter: Scale number Command 288 returns the gross weight value for the specified scale in floating-point format.

Read Net Weight as Float

Command: 289, 0x121 Parameter: Scale number Command 289 returns the net weight value for the specified scale in floating-point format.

Read Tare as Float

Command: 290, 0x122 Parameter: Scale number Command 290 returns the tare weight value for the specified scale in floating-point format.

Read Current Display as Float

Command: 293, 0x125

Parameter: Scale number

Command 293 returns the weight value for the specified scale as currently displayed in floating-point format. This may include gross, net, tare, or accumulator values, as enabled. The weight value is returned in the mode used to display a scale widget.

Read Accumulator as Float

Command: 294, 0x126

Parameter: Scale number

Command 294 returns the accumulator value for the specified scale in floating-point format. Batch status is returned in place of the indicator status.

Read Rate of Change as Float

Command: 295, 0x127

Parameter: Scale number

Command 295 returns the current rate of change value for the specified scale in floating-point format. This command is valid only for the 1280.

Set Setpoint Value as Float

Command: 304, 0x130 Parameter: Setpoint number

Value: Setpoint value

Command 320 sets the setpoint value for the specified setpoint in floating-point format. This command is valid only when the setpoint is configured and requires a setpoint value. Batch status is returned in place of the indicator status.

Set Setpoint Hysteresis as Float

Command: 305, 0x131 Parameter: Setpoint number

Value: Hysteresis value

Command 305 sets the hysteresis value for the specified setpoint in floating-point format. This command is valid only when the setpoint is configured and requires a hysteresis value. Batch status is returned in place of the indicator status.

Set Setpoint Bandwidth as Float

Command: 306, 0x132

Parameter: Setpoint number

Value: Bandwidth value

Command 306 sets the bandwidth value for the specified setpoint in floating-point format. This command is valid only when the setpoint is configured and requires a bandwidth value. Batch status is returned in place of the indicator status.



Set Setpoint Preact as Float

Command: 307, 0x133

Parameter: Setpoint number

Value: Preact value

Command 307 sets the preact value for the specified setpoint in floating-point format. This command is valid only when the setpoint is configured and requires a preact value. Batch status is returned in place of the indicator status.

Read Setpoint Value as Float

Command: 320, 0x140

Parameter: Setpoint number

Command 320 returns the target value for the specified setpoint in floating-point format. This command is valid only when the setpoint is configured and requires a target value. Batch status is returned in place of the indicator status.

Read Setpoint Hysteresis as Float

Command: 321, 0x141

Parameter: Setpoint number

Command 321 returns the hysteresis value for the specified setpoint in floating-point format. This command is valid only when the setpoint is configured and requires a hysteresis value. Batch status is returned in place of the indicator status.

Read Setpoint Bandwidth as Float

Command: 322, 0x142

Parameter: Setpoint number

Command 322 returns the bandwidth value for the specified setpoint in floating-point format. This command is valid only when the setpoint is configured and requires a bandwidth value. Batch status is returned in place of the indicator status.

Read Setpoint Preact as Float

Command: 323, 0x143

Parameter: Setpoint number

Command 323 returns the preact value for the specified setpoint in floating-point format. This command is valid only when the setpoint is configured and requires a preact value. Batch status is returned in place of the indicator status



Specifications 5.0

Power Requirements

Bus Adapter Card with EtherNet/IP Module, DC Power

Supply Voltage	6 VDC
Typical Current Draw	270 mA
Power Consumption	1.62 W
Maximum Current Draw	500 mA
Maximum Power	3 W

Communications Specifications

EtherNet/IP Network Communications Twisted-pair cabling at 10 or 100Mbps

Environmental Specifications

Temperature

-10°-40° C (14°-104° F)

Conformance



The EtherNet/IP Interface has been tested by ODVA's independent test lab and found to comply with the ODVA composite conformance test, revision 3.



The EtherNet/IP Interface has been found in accordance with EMC directive 89/336/EEC for CE European standards EN 50081-2 and EN 61000-6-2.



© Rice Lake Weighing Systems Specifications subject to change without notice. Rice Lake Weighing Systems is an ISO 9001 registered company.

230 W. Coleman St. • Rice Lake, WI 54868 • USA U.S. 800-472-6703 • Canada/Mexico 800-321-6703 • International 715-234-9171 • Europe +31 (0)26 472 1319

www.ricelake.com