



AutoLift HE



| REF# | PART#  | DESCRIPTION                                         | PRICE   |
|------|--------|-----------------------------------------------------|---------|
| 1    | 88956  | Junction box, NEMA 4X, 4-channel, signal trim ..... | Consult |
| 2    | 15611  | Cable, 6-wire, junction box to indicator .....      | Consult |
| 3    | 16141  | Cable ties, 8" (at back of assembly) .....          | Consult |
| 4    | 46258  | Load cell screw .....                               | Consult |
| 5    | 18756  | Foot assembly.....                                  | Consult |
| 6    | 106039 | Load cell, RLH35 1000 lb (2000 lb scale).....       | Consult |
| 6    | 106040 | Load cell, RLH35 2500 lb (5000 lb scale).....       | Consult |
| 6    | 106041 | Load cell, RLH35 4000 lb (10,000 lb scale).....     | Consult |

(See Diagram AutoLift HE-A)




AutoLift HE-A

# AutoLift HE (cont.) Pneumatic Control Box



| REF# | PART# | DESCRIPTION                         | PRICE   |
|------|-------|-------------------------------------|---------|
| 1    | 42285 | Enclosure, pneumatic.....           | Consult |
| 2    | 44175 | Bulkhead connector, 5/16.....       | Consult |
| 3    | 42260 | Tubing, clear polyurethane.....     | Consult |
| 5    | 42282 | Fitting, 1/8 female.....            | Consult |
| 6    | 42281 | Adjustable flow control.....        | Consult |
| 7    | 42268 | Brass nipple, 1/8 NPT x 3/4 in..... | Consult |
| 8    | 42280 | Valve adapter, pushbutton.....      | Consult |
| 9    | 42279 | Pushbutton, acuator, key.....       | Consult |
| 11   | 42277 | Control valve, three way spool..... | Consult |
| 12   | 42276 | Brass nipple, 1/8 NPT x 2 in.....   | Consult |
| 13   | 42275 | Fitting, 1/8 male straight.....     | Consult |
| 14   | 42274 | Check valve, poppet type.....       | Consult |
| 15   | 42273 | Fitting, 1/8 male elbow.....        | Consult |
| 16   | 42272 | Adjustable flow control.....        | Consult |
| 17   | 42271 | Fitting, 1/8 NPT bulkhead.....      | Consult |
| 18   | 42270 | Muffler, 1/8 NPT porous.....        | Consult |
| 19   | 42259 | Tubing, clear polyurethane.....     | Consult |
| 20   | 42258 | Tubing, clear polyurethane.....     | Consult |
| 22   | 15631 | Cable tie, 3 in nylon.....          | Consult |

(See Diagram AutoLift HE-B)



AutoLift HE-B


AutoLift HE (cont.) Pneumatic Lift Scale



| REF# | PART# | DESCRIPTION                                                         | PRICE   |
|------|-------|---------------------------------------------------------------------|---------|
|      | 42267 | Air filter/regulator and lubricator with semi automatic drain ..... | Consult |
|      | 44141 | Operating manual.....                                               | Consult |
| 1    | 41936 | Pit coping WLDT, 4' x 4'.....                                       | Consult |
| 1    | 41937 | Pit coping WLDT, 5' x 5'.....                                       | Consult |
| 3    | 42261 | Exhaust muffler/filter.....                                         | Consult |
| 5    | 42265 | Air cylinder, 5' x 5', 3" bore, 20" stroke.....                     | Consult |
| 5    | 42266 | Air cylinder, 4' x 4', 3" bore, 15" stroke.....                     | Consult |
| 7    | 42263 | Rod clevis, nut and cotter pins.....                                | Consult |
| 8    | 42310 | Clevis pin.....                                                     | Consult |
| 9    | 35356 | Cotter pin.....                                                     | Consult |

(See Diagram AutoLift HE-C)

Floor Scales



AutoLift HE-C